

快速乾燥機系列 High Speed Dryer





燁品企業有限公司 YE PIN CO., LTD

目錄 Catalog

中文 Chinese	英文 English	頁數 Page
功能特色-4大提升	Feature-4 UPs	P2
功能特色-6大降低	Feature-6 Downs	P3
7大優勢結構	7 advantage structures	P4
乾燥效率比較	Compare Drying Efficiency	P5
含水率太高,對塑料的破壞	Water content rate is too high, it will be damage to plastic	P6
相對濕度、含水率、物性相互 關係	Relationship between Relative humidity, Water content rate, Physical properties	P7
作動原理	What' s principle?	P8
化學吸附乾燥機 VS YP乾燥機	Chemical adsorption dryer VS YP Dryer	P9
第一回,省錢,省時,省電	Round One, SaveTime,Money,Electriciity	P10
第二回,結構	Round Two ,Structure	P12
第三回 ,環境	Round Three, Environment	P13
多功能快速乾燥機	Multi-function High Speed Dryer	P14
光學級快速乾燥機	Optics High Speed Dryer	P18
BD 微電腦快速乾燥機	BD Microprocessor Controlled High Speed Dryer	P22
LD 微電腦快速乾燥機	LD Microprocessor Controlled High Speed Dryer	P26


功能特色--4大提升 Features—4 Up



- 提高產品的抗拉性、抗破性、透光率、耐久性
- Increasing tensile resistance, fracture resistance, transparency, durability



- 提高成型品的良率及品質
- Increasing product validity and quality



- 提高份子之間的連結
- Increasing molecule combination



- 提高生產的稼動率
- · Increasing production mobility

功能特色--6大降低 Features--6 Downs



- 減少一半的烘料時間
- · shorten half time of drying



- 降低含水率200 ppm以下
- Reducing water contain rate under 200ppm



- 降低烘料成本,節省電費40%以上
- Reducing electricity bill more than 40%



- •減少模具清洗的次數 (PA46,PPS)
- Reducing cleaning frequency of mold(PA46,PPS)



- 減少乾燥不完全所產生的不良(流紋、氣泡..等)
- Reducing defects of incomplete drying (such as streak, bubble....etc.)



- 降低原料成型時,經過料管高溫混煉的所產生的氣體
- Reducing the generation of gas during the injection molding

7大優勢結構

7 Structures





不用接冷卻水 No cooling water



不銹鋼外殼易保養 Easy maintenance for stainless steel case



集塵器 Dust Collector



LED微電腦式控制面板 LED microprocessor controlled panel



功能均用燈號顯示 Light display function



機台可移動 Moveable



外罩式過濾器清理容易 Easy clean for outer filters

- 多功能快速乾燥機搭配專利截料閥,使 輸送管內的塑料不殘留,無塑料回潮的 問題。
- Multi-function high speed dryer device is equipped with patented valve to completely clean the plastic residue such that there will be no plastic material re-dampening problem.

專利截料閥 Patented Valve




由語多國惠利結構

Multi-national patent application structure

乾燥效率比較 Compare drying efficiency





乾燥時間/小時 Drying Time / Hr	PPS	ABS	PPA	PMMA	PETG	PC	PET	PA	LCP
它牌 Other Brand	3	4	4	4	4	4	6	6	6
YP乾燥機 YP Dryer	2	2	2	2	2	1.5	2	2	2

含水率太高,對塑料之破壞

Water content rate is too high, it will be damage to plastic


氣泡 起瘡 **Bubble** 銀線 Rough Sliver line bubble 衝擊性差 尺寸不穩 Unstable Bad durability Size 製品碎裂 黏度不佳 **Product** Bad adhesive **Splintering** 水解 龜裂 Hydrolysis Creaking 流痕 Streak


若要生產高質量的塑膠製品必須先注意到 "前端塑料的乾燥處理" If you would like to produce high quality plastics, you must be aware of "drying process before injection molding".

相對濕度、含水率、物性相互關係

Relationship between Relative humidity, Water content rate, Physical properties

相對濕度% Relative humidity% 空氣中相對對濕度過高時,塑料就會快速吸濕,使塑料的含水率增加 Relative humidity is too high in the air, plastic will humidify quickly, it will increase water content rate.







作動原理?

What's principle?

低氣壓使水的沸點降低 Low pressure makes boiling point of water lower.










在喜馬拉亞山水的沸點是73℃ Boiling point of water in the Himalayas is 73℃.



在高山水的沸點是80°C~90°C Boiling point of water in high mountain is 80°C~90°C.





高氣壓 High pressure

燁品的快速乾燥機的乾燥原理,是用物理原理,非化學吸附。簡易的說:快速乾燥機將空氣吸入,產生低壓的氣漩經過加熱,將乾燥的熱風打入料桶,將塑料中的水份子蒸發,(使露點的溫度達-40°℃以下)。

Our High speed dryer uses "physical principle", not chemical absorbing. Let me explain to you: Air had been sucked by our high speed dryer, producing low pressure air, the low pressure air through heater. It becomes drying hot air into hopper to make moisture of plastic to vaporize.(reach dew point under -40°C)




化學吸附乾燥機

Chemical adsorption dryer

VS YP乾燥機

VS YP Dryer



VS



決戰三回合 Three round battle

第一回,省錢,省時,省電

Round One, Save Time, Money, Electricity

化學吸附乾燥機 Chemical adsorption dryer



YP 乾燥機 YP dryer



額外的工程費用 Additional project costs

要接水管 Link water pipe



無 No



要維持室內恆溫, 冷氣需持續的運作 In order to maintain the indoor temperature, airconditioning needs to continue operations

冷氣費用 Air-conditioning costs



無 No



耗 材 費 用 Consumables cost



低 Low



第一回,省錢,省時,省電 Round One, Save Time, Money, Electricity

化學吸附乾燥機 Chemical adsorption dryer







乾燥時間 Clean room

如: PC要_{3~4}小時 LCP要6~8小時

For example: PC needs about 3~4 hours of drying time. LCP needs about 6~8 hours of drying time.



如: PC要2小時 LCP要2小時

For example: PC needs about 2 hours of drying time. LCP needs about 2 hours of drying time.

耗 電 量 Power consumption

高耗電量

High power Consumption.



低耗電量·約化學 吸附乾燥機的一半



Low power consumption, power consumption is about one half of chemical adsorption dryer.

第二回,結構

Round Two, Structure

化學吸附乾燥機 Chemical adsorption dryer



YP 乾燥機 YP dryer



要接冷卻水 It need to link cooling water.

冷 卻 水 Cooling Water




不接冷卻水 No cooling water



白鐵烤漆,易掉漆生鏽 Painted iron, easy to peel off and get rusty.

外 殼 Outer Case



SUS₃04不銹鋼,耐久不生鏽 SUS₃04 stainless steel, durable and not easy to rust.



如:烘PA會出油,蜂巢和分子篩會阻塞 For example: Drying PA Will be out of oil. Honeycomb and molecular sieve will be clogged.

分子篩 Molecular sieve



沒有分子篩, 具有專利機芯 結構,沒有阻 塞的疑慮



No molecular sieve, dryer is equipped with patented cassette mechanism structure, no doubt for clogging.

第三回 ,環境 Round Three, Environment




化學吸附乾燥機 Chemical adsorption dryer



YP 乾燥機 YP dryer



潔淨的無塵室 Clean room





氣 排 放

適用,無漏水的 可能性 Suitable, no leaking water possibility.



Exhausting hot air



無 No exhausting hot air.



It exhausts hot air.

會排出熱氣

多功能快速乾燥機 Multi-function High Speed Dryer

多功能乾燥機具有 如下特點:


- 1.吸料和送料
- 2.除濕乾燥
- 3.除粉

Multi- function dryer has below features:

1. Suction feeder and Autoloader

2.Dehumidifying

3. Eliminating powder






除粉,是指將顆粒的塑料經碰撞所產生的粉末,加以去除

Eliminating powder - means powder produced by the plastic pellet collision

多功能快速乾燥機-結構 Multi-function high speed dryer -Structure



空氣濾清器 Air Filter



空氣噴槍 Air spray gun

警報響起,請用空氣噴槍清潔空氣濾清 器即可。

Alarm will be buzzing, please use air spray gun to clean air filter.

旋風式集塵器,將底部集塵盒取出雜質 倒掉即可。


Cyclone dust collector, Taking bottom dust collector to pour impurities.

多功能快速乾燥機搭配專利截料閥, 使輸送管內的塑料不殘留,無塑料回潮的問題。 Multi-function high speed dryer device is equipped with patented valve to completely clean the plastic residue such that there will be no plastic material re-dampening problem.



多功能快速乾燥機-示意圖

Multi-function high speed dryer - Schematic diagram



A:YP乾燥機吸風

A:Wind has been sucked by YP dryer.

B:將塑料抽入料桶中

B:Plastic material send into hopper.

C:YP乾燥機吸風

C:Wind has been sucked by YP dryer.

D:將乾燥完成的塑料送至成型機或押出機

D:Drying completed plastic material send into injection molding machine or extruder machine.

YP 快速乾燥機適用在各種射出機或押出機上

YP high speed dryer is suitable for all kinds of injection molding machine or extruder machine.



依客戶需求,乾燥機可搭配儲料桶, 報價不含儲料桶價格

Depend on customer demand, our dryer could equipped with storage can, price does not include storage can price.



多功能快速乾燥機規格表 Multi-function High Speed Dryer Specification

型式 Model		HS-015MD	HS-025MD	HS-050MD	HS-100MD	HS-200MD
乾燥風量(m3/hr) Drying wind rate		30	30	60	120	240
總瓦特數(kw) Total wattage		3.26	3.26	3.95	5.00	7.15
料桶容量(kg) Hopper capacity		15	25	50	100	200
尺寸 Size (mm)	寬度 Width	660	530	530	730	860
	深度 Depth	1220	1090	1090	1250	1500
	高度 High	1680•2160	1680•2160	1680•2160	1780•2250	2040•2475
重量 Weight(kg)		217	217	245	353	473

^{*}此機台為連續式適用於所有塑料、生產用、實驗室

17

^{*}This machine is continuous and suitable for all plastics ,production, and laboratory.

光學級快速乾燥機

Optics High Speed Dryer



光學級乾燥機具有如下特點:

- 1.吸料和镁料
- 2.除濕乾燥

Optics Dryer has below features:


- 1. Suction feeder and Autoloader
- 2. Dehumidifying

除濕乾燥 Dehumidifying 吸料和送料 Suction Feeder And Autoloader

光學級快速乾燥機適用在高精密的工程塑料如:光學級PC,光學級PET,光學級PMMA,等。 Optics high speed dryer is suitable for engineering plastics of high precision. Such as PET, PMMA, PC of optics....ext.

光學級快速乾燥機-結構 Optics high speed dryer-Structure





警報響起,請用空氣噴槍清潔 空氣濾清器即可。


Alarm will be buzzing, please use air spray gun to clean air filter.

此為旋風式集塵器,用來捕集吸 料機所排出的大雜質,將底部集 塵盒取出雜質倒掉即可。

↑This is cyclone dust collector. In order to collect big impurities which discharged from suction feeder. Taking bottom dust collector to pour impurities.

光學級快速乾燥機-示意圖

Optics high speed dryer-Schematic diagram



A: YP乾燥機吸風

A: Wind has been sucked by YP dryer.

B:將塑料抽入料桶中

B:Plastic material send into hopper.

C: YP乾燥機將乾燥的風打入料桶中

C: YP dryer send drying wind into hopper.

D:料桶中排放出的雜質送至YP集 塵盒

D:Collecting impurities which discharged from hopper send into dust collector.

YP 快速乾燥機適用在各種射出機或押出機上

YP high speed dryer is suitable for all kinds of injection molding machine or extruder machine.



依客戶需求,乾燥機可搭配儲料桶, 1報價不含儲料桶價格

Depend on customer demand, our dryer could equipped with storage can, price does not include storage can price.



光學級快速乾燥機規格表 Optics High Speed Dryer Specification

型式 Model		HS-oo6 <mark>OD</mark>	HS-015 <mark>OD</mark>	HS-025 <mark>OD</mark>	HS-050 <mark>OD</mark>
	徑(inch) :let air pipe	2"	2" 2.5"		2.5"
电熱助率 Electric h	(kw) eating power	2.29	2.59	2.59	3.20
總瓦特數 Total watt		2.95	3.25	3.40	3.70
送料風機 (kw) Feeder blower		0.75	0.75	0.75	0.75
尺寸 Size	寬度 Width (mm)	462	462	462	462
	深度 Depth (mm)	690	690	690	690
3120	高度 High (mm)	1330	1430	1430	1430
重量 Weight(kg)		65	72	72.5	75

^{*}此機台為連續式適用於所有塑料、生產用、實驗室

^{*}This machine is continuous and suitable for all plastics ,production, and laboratory.

BD微電腦快速乾燥機

BD Microprocessor Controlled High Speed Dryer



BD 微電腦快速乾燥機適用如下:

- 1.射出量大的生產
- 2.押出量大的生產
- 3.經常性換料生產

BD microprocessor controlled high speed dryer is suitable for below items.

- 1.Big injection molding production.
- 2.Big extruding production.
- 3. Frequently changing plastic production



BD 乾燥幾系列-結構 BD Dryer Series- Structure

閥門 Switch


空氣濾清器 Air Filter 空氣噴槍 Air spray gun

警報響起,請用空氣噴槍清潔空氣 濾清器即可。

Alarm will be buzzing, please use air spray gun to clean air filter.

乾燥的風送至料桶 Drying wind send to hopper. <

此為集塵器,用來收集料桶所排出的雜質 < This is dust collector. In to order to collect impurities which discharged from hopper.



↑ Close ↓ Open

↑ Close


↓ Open

關開


關

開

BD乾燥機系列-示意圖 BD dryer Series-Schematic diagram



A: YP乾燥機送乾燥的風送至料桶中 A: YP dryer send drying wind into hopper.



B:雜質和含有濕度的空氣送入集塵盒中 B:Impurities and air of comprising humidity send into dust collector.

1台BD系列乾燥機可連1~4料桶 One HS series dryer could connect 1~4 hoppers.

YP 快速乾燥機適用在各種射出機 或押出機上

YP high speed dryer is suitable for all kinds of injection molding machine or extruder machine.







BD 微電腦快速乾燥機規格表 BD Microprocessor Controlled High Speed Dryer Specification

型式 Model		HS-025BD	HS-050BD	HS-100BD	HS-200BD	HS-400BD	HS-600BD	HS-800BD
乾燥風 (m3/hr Drying v		30	60	120	220	460	585	850
總瓦特 Total wa	數(kw) attage	2.59	3.20	4.25	6.40	10.60	14.60	16.60
尺寸 Size (mm)	寬度 Width	510	510	535	561	612	637	637
	深度 Depth	869	869	958	993	1062	1096	1116
	高度 High	1515	1515	1573	1631	1747	1805	1805
重量 Weight(kg)		по	130	185	236	381	420	547

^{*}此機台為連續式適用於所有塑料、生產用、實驗室

^{*}This machine is continuous and suitable for all plastics ,production, and laboratory.

LD微電腦快速乾燥機

LD Microprocessor Controlled High Speed Dryer



LD 微電腦快速乾燥機適用如下:

1.射出量小的生產

2.押出量小的生產

3.經常性換料生產



LD microprocessor controlled high speed dryer is suitable for below items.


- 1.Small injection molding production.
- 2.Small extruding production.
- 3. Frequently changing plastic production

LD乾燥幾系列-結構 LD Dryer Series- Structure

隱藏式過濾網 < Concealed Filter

乾燥的風送至料桶 ← Drying wind send to hopper.


雜質和潮溼的風送至集塵器 Impurities and moist wind send to dust collector.



此為集塵器,用來收集料桶所排出的雜質 This is dust collector.

In to order to collect impurities which discharged from hopper.

LD乾燥幾系列-示意圖 LD Dryer Series -Schematic diagram



A: YP乾燥機送乾燥的風送至料桶中 A: YP dryer send drying wind into hopper. B:雜質和含有濕度的空氣送入集塵盒中B:Impurities and air of comprising humidity send into dust collector.

YP 快速乾燥機適用在各種射出機或押出機上 YP high speed dryer is suitable for all kinds of injection molding machine or extruder machine.







LD 微電腦快速乾燥機規格表 LD Microprocessor High Speed Dryer Specification

型式 Model		HS-025LD HS-050LD		HS-100LD	HS-200LD
乾燥風量 (m3/hr) Drying wind rate		45	60	120	220
總瓦特數 (kv Total wattage		2.59	3.20	4.25	6.40
尺寸 Size (mm)	寬度 Width	360	360	395	395
	深度 Depth	750	750	780	780
	高度 High	1180	1180	1332	1332
重量 Weight(kg)		66.2	68.o	97-5	115.0

^{*}此機台為連續式適用於所有塑料、生產用、實驗室

29

^{*}This machine is continuous and suitable for all plastics ,production, and laboratory.

YP快速乾燥機 YP High Speed Dryer

省錢 Save Money 快速 **High Speed** 節能 Save Energy

燁品企業有限公司

電話:+886-3-409-0577 傳真:+886-3-409-3381

網址:www.ye-pin.com.tw

國內聯絡e-mail: yepin.com@msa.hinet.net 國外聯絡e-mail: service@ye-pin.com.tw

YE PIN CO., LTD.

TEL:+886-3-409-0577 FAX:+886-3-409-3381

Website: www.ye-pin.com.tw

Domestic contact e-mail: yepin.com@msa.hinet.net Foreign contact e-mail: service@ye-pin.com.tw